

**NATURAL RESOURCES CONSERVATION SERVICE  
CONSERVATION PRACTICE STANDARD**

**STRUCTURE FOR WATER CONTROL**

(Each)

**CODE 587**

**DEFINITION**

A structure in an irrigation, drainage, or other water management systems that conveys water, controls the direction or rate of flow, or maintains a desired water surface elevation.

**PURPOSE**

To control the stage, discharge, distribution, delivery, or direction of flow of water in open channels or water use areas. Also used for water quality control, such as sediment reduction or temperature regulation. These structures are also used to protect fish and wildlife and other natural resources.

**CONDITIONS WHERE PRACTICE APPLIES**

This practice applies wherever a permanent structure is needed as an integral part of an irrigation, drainage, or other water-control systems to serve one or more of the following functions:

1. To conduct water from one elevation to a lower elevation within, to, or from a ditch, channel, or canal. Typical structures: drops, chutes, turnouts, surface water inlets, head gates, pump boxes, and stilling basins.
2. To control the elevation of water in drainage or irrigation ditches. Typical structure: checks.
3. To control the division or measurement of irrigation water. Typical structures: division boxes and water measurement devices.
4. To keep trash, debris, or weed seeds from entering pipelines. Typical structure: debris screens.

5. To control the direction of channel flow resulting from tides and high water or backflow from flooding. Typical structure: tide and drainage gates.
6. To control the level of a water table or to remove surface or subsurface water from adjoining land, to flood land for frost protection or to manage water levels for wildlife or recreation. Typical structures: water level control structures, pipe drop inlets, and box inlets.
7. To provide water control for recreation or similar purposes.
8. To convey water over, under, or along a ditch, canal, road, railroad, or other barriers. Typical structures: bridges, culverts, flumes, inverted siphons.
9. To modify water flow to provide habitat or fish, wildlife, and other aquatic animals. Typical structures: deflectors, chutes, cold water release, or structures to make pools and riffles.

**CRITERIA**

Structures shall be designed on an individual job basis, or applicable NRCS standard drawings shall be adapted, to meet site conditions and functional requirements. They shall be part of an approved and overall engineering plan for irrigation, drainage, wildlife, recreation, channel improvement, or similar purposes.

Designs shall include provisions to prevent erosion and other damage upstream and downstream of the point of discharge.

Conservation practice standards are reviewed, and updated if needed. To obtain the current version of this standard, contact the Natural Resources Conservation Service.

The plan shall specify the location, grades, dimensions, materials, and hydraulic and structural requirements for the individual structure. Provisions must be made for necessary maintenance. Care must be used to insure that the area's visual resources are not damaged. If watercourse fisheries are important, special precautions or design features may be needed to insure continuation of fish migrations.

If soil and climatic conditions permit, a protective cover of vegetation shall be established on all disturbed earth surfaces. If soil or climatic conditions preclude the use of vegetation and protection is needed, non-vegetative means, such as mulches or gravel, may be used. In some places, temporary vegetation may be used until permanent vegetation can be established. The structure can be fenced, if necessary, to protect the vegetation. Seedbed preparation, weeding, fertilizing, and mulching shall comply with the instructions in technical guides.

**Culverts.** Culverts as temporary measures, with a life span of less than 2 years, shall carry as a minimum the 2-year, 24 hour-duration storm. Diversions that protect agricultural land and those that are part of a pollution abatement system must have the capacity to carry the peak runoff from a 10-year-frequency, 24-hour-duration storm as a minimum.

Culverts designed to protect areas such as urban areas, buildings, and roads, shall have enough capacity to carry the peak runoff expected from a storm frequency consistent with the hazard involved but not less than a 25-year-frequency, 24-hour-duration.

The minimum inside diameter of culvert pipe shall be 12 inches. At least one foot of cover shall be required for all culverts.

In streams with bed load of gravel sizes and design velocities greater than 14 fps, culverts should normally be constructed of corrugated galvanized metal pipe or corrugated aluminum pipe. The use of two-foot coupling bands on metal pipes with velocities greater than 14 fps shall be called for on the plans. Metal pipes placed on grades more than 20% may require special anchoring details. The use of culvert pipes on steep grades should be restricted to the smaller sizes.

Treatments such as sloped riprap, headwalls, metal or plastic end sections and/or energy dissipaters shall be used in areas of high flow velocities and high turbulence.

In areas where over topping is possible an auxiliary spillway shall be installed or other measures shall be installed to protect fill over and around the culvert from erosion.

## CONSIDERATIONS

### *Water Quantity*

1. Effects on the water budget, especially on volumes and rates of runoff, infiltration, evaporation, transpiration, deep percolation, and ground water recharge.
2. Potential for a change in the rate of plant growth and transpiration because of changes in the volume of soil water.
3. Effects on downstream flows or aquifers that would affect other water uses or users.
4. Effects on the volume of downstream flow that might cause environmental, social or economic effects.
5. The effect on the water table of the field to ensure that it will provide a suitable rooting depth for the anticipated crop.
6. Potential use for irrigation management to conserve water.

### *Water Quality*

1. Effects on erosion and the movement of sediment and soluble and sediment-attached substances carried by runoff.
2. Effects on the movement of dissolved substances below the root zone and to ground water.
3. Short term and construction-related effects of this practice on the quality of downstream water.
4. Effects of water level control on the temperatures of downstream waters for their effects on aquatic and wildlife communities.

5. Effects on wetlands or water-related wildlife habitats.
6. Effects on the visual quality of downstream water resources.

## **PLANS AND SPECIFICATIONS**

Plans and specifications for installing structures for water control shall be in keeping with this standard and shall describe the requirements for applying the practice to achieve its intended purpose.

## **OPERATION AND MAINTENANCE**

An operation and maintenance plan shall be prepared for use by the owner or others responsible for operating and maintaining the system. The plan shall provide specific instructions for operating and maintaining the system to insure that it functions properly. It shall also provide for periodic inspections and prompt repair or replacement of damaged components or erosion.